


Boiler control panel

(ALL ATAG BOILER RANGE)



Controller buttons

A	Selector Wheel Turn the wheel left or right to scroll through available menu options
B	OK button Press to select/confirm an item
C	BACK button Press to go back one screen
D	RESET button Press to reset a fault code
E	Chimney sweep button Press to enter into service mode which button allows adjustment of high fire/low fire and CO2 settings

Controller display

1	DHW comfort or economy mode is active	10	Current central heating system water pressure
2	DHW status symbol. A box around the tap symbol indicates DHW is in operation	11	Boiler status indicator, such as "Press OK to enter Menu", error messages and other status information
3	Visual illustration of current hot water temperature. Scale changes as the set temperature is changed	12	Heating supply setpoint
4	Internal room temperature (if present)	13	Outdoor temperature (if connected)
5	DHW set point temperature	14	Time program
6	CH time program active	15	Visual illustration of current central heating temperature. Scale changes as the set temperature is changed
7	Flame Burner on	16	Central heating status symbol. A box around the radiator symbol indicates central heating is in operation
8	Current date and time	17	Thermoregulation function enabled
9	Actual Power Level		